

EASY INSTALL

AVERAGE INSTALL TIME IS
14 MINUTES



STEP 1 MEASURE

- A) CENTER LOCK ON DOOR
- B) CONFIRM HEIGHT



STEP 2 DRILL

- A) MARK AND DRILL PILOT HOLES WITH TEMPLATE
- B) CLEAN SURFACE



STEP 3 SECURE

- A) PLACE UNIT OVER PILOT HOLES
- B) DRILL IN 6 SCREWS (PROVIDED)

when the wedge is in locked and in the up position, the lock is 1.5 inches tall. The lifted gate will need to catch 0.25 inches of the door to be effective.



 **HAVEN**

install.havenlock.com

<https://install.havenlock.com>

support@havenlock.com