










THE LOCK IS PRESET AT 0-0-0-0

HOW TO RESET AND USE:



- 1 Turn the dial wheels to preset number 0-0-0-0.
- 2 Pull up shackle and turn away from hole.
- 3 Use a screw driver to turn the "screw" vertically like "⊕" until reach the "click" point.
- 4 Set the dial wheels to your own numbers, new combination is now set. (Write down new combination and keep it in the safe place.)

- 5 Remember to turn the "screw" back to horizontally like "⊖", otherwise the combination will be mixed up.
- 6 After setting up your own numbers, you can slide up the side lid to store the key into the compartment.
- 7 Always have the rubber side (back side) facing you before placing the lock on the object.
- 8 Turn the lock 180° to close with front side facing you. Push down shackle until you hear a "click" sound.
- 9 Spin the dial wheels to random numbers to lock.